

Kit 1019




AUDI A4, 4-dr Sedan, 95-00 / *95-01

AUDI S4, 4-dr Sedan, 97-01/ *00-02

AUDI A4 Avant, 5-dr Estate, 96-01

AUDI A4, 5-dr Wagon, *97-01

*North America








THULE[®]
SWEDEN


ISO 11154-E

**Max.
60 kg**
**Max.
132 lbs**


Kit



3




754



750

1




2




	X
AUDI A4, 4-dr Sedan, 95-00 / *95-01	28
AUDI S4, 4-dr Sedan, 97-01/ *00-02	28
AUDI A4 Avant, 5-dr Estate, 96-01	27,5
AUDI A4, 5-dr Wagon, *97-01	27,5

1



2



	Y
AUDI A4, 4-dr Sedan, 95-00 / *95-01	26
AUDI S4, 4-dr Sedan, 97-01/ *00-02	26
AUDI A4 Avant, 5-dr Estate, 96-01	23,5
AUDI A4, 5-dr Wagon, *97-01	23,5




480R



480

1




2




	X inch	X mm
AUDI A4, 4-dr Sedan, 95-00 / *95-01	36 ⁵ / ₈ "	931 mm
AUDI S4, 4-dr Sedan, 97-01/ *00-02	36 ⁵ / ₈ "	931 mm
AUDI A4 Avant, 5-dr Estate, 96-01	36 ¹ / ₂ "	926 mm
AUDI A4, 5-dr Wagon, *97-01	36 ¹ / ₂ "	926 mm

1



2



	Y inch	Y mm
AUDI A4, 4-dr Sedan, 95-00 / *95-01	35 ⁷ / ₈ "	911 mm
AUDI S4, 4-dr Sedan, 97-01/ *00-02	35 ⁷ / ₈ "	911 mm
AUDI A4 Avant, 5-dr Estate, 96-01	34 ⁷ / ₈ "	886 mm
AUDI A4, 5-dr Wagon, *97-01	34 ⁷ / ₈ "	886 mm







4

AUDI A4, 4-dr Sedan, 95-00 / *95-01







AUDI S4, 4-dr Sedan, 97-01/ *00-02

AUDI A4 Avant, 5-dr Estate, 96-01

AUDI A4, 5-dr Wagon, *97-01



5



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Serrare alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťta багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın

中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชั้ในแบบสลับ






6





480R/754




480






750






i








i



i





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		