



Kit 1200

FORD Escape, 5-dr SUV, 00-07



FORD Maverick, 5-dr SUV, 01-07

MAZDA Tribute, 5-dr SUV, 00-03, 04-07



**480R
754**



480



750



THULE[®]
SWEDEN

ISO 11154-E

**Max.
50kg**
**Max.
110 lbs**

x1

x4

x4

x4

x4

x1

x4

x4

x4

x4

x1

x4

x4

x4

x4

x2	x2	x2	x2	x2
x2	x2	x2	x2	x2
x2	x2	x2	x2	x2
x4	x4	x4	x4	x4

x1

x4

x4

x1

x1

Kit

1




480R/754



480



750



2



480R/754














480




750



+



3





754



750



1




2




	X
FORD Escape, 5-dr SUV, 00-07	37
FORD Maverick, 5-dr SUV, 01-07	37
MAZDA Tribute, 5-dr SUV, 00-03, 04-07	37

1



2



	Y
FORD Escape, 5-dr SUV, 00-07	36,5
FORD Maverick, 5-dr SUV, 01-07	36,5
MAZDA Tribute, 5-dr SUV, 00-03, 04-07	36,5




480R



480

1




2



	X inch	X mm
FORD Escape, 5-dr SUV, 00-07	40 1/4"	1021 mm
FORD Maverick, 5-dr SUV, 01-07	40 1/4"	1021 mm
MAZDA Tribute, 5-dr SUV, 00-03, 04-07	40 1/4"	1021 mm

1



2









	Y inch	Y mm
FORD Escape, 5-dr SUV, 00-07	40"	1016 mm
FORD Maverick, 5-dr SUV, 01-07	40"	1016 mm
MAZDA Tribute, 5-dr SUV, 00-03, 04-07	40"	1016 mm

4


FORD Escape, 5-dr SUV, 00-07

FORD Maverick, 5-dr SUV, 01-07





MAZDA Tribute, 5-dr SUV, 00-03, 04-07



5



	X mm	Y mm	X inch	Y inch
FORD Escape, 5-dr SUV, 00-07	290 mm	700 mm	11 3/8"	27 1/2"
FORD Maverick, 5-dr SUV, 01-07	290 mm	700 mm	11 3/8"	27 1/2"
MAZDA Tribute, 5-dr SUV, 00-03, 04-07	290 mm	700 mm	11 3/8"	27 1/2"




GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно

CZ Pokrýtla багажника dokręcaj dokręcaj naprzemiennie.
SK Doťahujte striedavo
SLO Privijajte izmenično.
HR Naizmjenično zategnite
HU Egy mástól függetlenül szorítandó
GR Σφίγγετε εναλλάξ
TR Dönüşümlü sıkın

中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ชันในแบบสลับ



6




480R/754





480




750








4 Nm



750





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		