













Kit 1260

CHRYSLER Voyager, 5-dr MPV, 01-07


CHRYSLER Grand Voyager, 5-dr MPV, 01-07








3




754




750



1



2




CHRYSLER Voyager, 5-dr MPV, 01-07
CHRYSLER Grand Voyager, 5-dr MPV, 01-07

X


37

37

1



2



CHRYSLER Voyager, 5-dr MPV, 01-07
CHRYSLER Grand Voyager, 5-dr MPV, 01-07

Y

37

37




480R



480

1



2



X inch

X mm

CHRYSLER Voyager, 5-dr MPV, 01-07

40 1/4"


1021 mm

CHRYSLER Grand Voyager, 5-dr MPV, 01-07

40 1/4"

1021 mm

1



2



Y inch

Y mm

CHRYSLER Voyager, 5-dr MPV, 01-07

40 1/4"

1021 mm














CHRYSLER Grand Voyager, 5-dr MPV, 01-07

40 1/4"


1021 mm

4




CHRYSLER Voyager, 5-dr MPV, 01-07
CHRYSLER Grand Voyager, 5-dr MPV, 01-07



5




	X mm	Y mm	X inch	Y inch
CHRYSLER Voyager, 5-dr MPV, 01-07	610 mm	700 mm	24 "	27 1/2 "
CHRYSLER Grand Voyager, 5-dr MPV, 01-07	610 mm	700 mm	24 "	27 1/2 "



GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно

CZ Pokręťla bagażníka dokręcaj dokręcaj naprzemiennie.
SK Dofahujte striedavo
SLO Privijajte izmenično.
HR Naizmjenično zategnite
HU Egymástól függetlenül szorítandó
GR Σφιγγείτε εναλλάξ
TR Dönüşümlü sıkın
中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ขันในแบบสลับ



6






480R/754








480



750





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		