



Kit 1310


TOYOTA Kluger V, 5-dr SUV, 00-06

TOYOTA Highlander, 5-dr SUV, 00-06



480R
754



480



750



THULE[®]
SWEDEN

ISO 11154-E

**Max.
60 kg**
**Max.
132 lbs**

Kit XXXX
instructions

480R/754

480

750

x2 x2 x2 x4	x2	x2 x2 x4 x4	x2 x2	x2

587 x 2






588 x 2

07 x 2


137 x 2

x 1



Kit



3




754




750



1




2




	X
TOYOTA Kluger V, 5-dr SUV, 00-06	44,5
TOYOTA Highlander, 5-dr SUV, 00-06	44,5

1



2



	Y
TOYOTA Kluger V, 5-dr SUV, 00-06	42
TOYOTA Highlander, 5-dr SUV, 00-06	42




480R



480

1




2



	X inch	X mm
TOYOTA Kluger V, 5-dr SUV, 00-06	43 1/8"	1096 mm
TOYOTA Highlander, 5-dr SUV, 00-06	43 1/8"	1096 mm

1










2




	Y inch	Y mm
TOYOTA Kluger V, 5-dr SUV, 00-06	42 1/8"	1071 mm
TOYOTA Highlander, 5-dr SUV, 00-06	42 1/8"	1071 mm

4




TOYOTA Kluger V, 5-dr SUV, 00-06
TOYOTA Highlander, 5-dr SUV, 00-06



5



	X mm	Y mm	X inch	Y inch
TOYOTA Kluger V, 5-dr SUV, 00-06	460 mm	710 mm	18 1/8"	28"
TOYOTA Highlander, 5-dr SUV, 00-06	460 mm	710 mm	18 1/8"	28"



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pielvelciēt pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte багажníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ขันในแบบสลับ



6






480R/754








480



750





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		