




Kit 1430

NISSAN Frontier, 4-dr Crew Cab Pickup, 05–
NISSAN Frontier, 4-dr King Cab Pickup, 05–
NISSAN King Cab, 4-dr Pickup Double Cab, 05–*
NISSAN Navara, 4-dr Pickup Double Cab, 05–*
NISSAN Pathfinder, 5-dr SUV, 05–*


* Without roof railing



754 Rapid System
480R Rapid Traverse (North America)



480 Traverse (North America)



THULE[®]
 SWEDEN

ISO 11154-E

754 Rapid System **x1**

480R Rapid Traverse (North America) **x1**

754 Rapid System **x4**

480R Rapid Traverse (North America) **x4**

754 Rapid System **x4**

480R Rapid Traverse (North America) **x4**




Europe		North America	
			
			
			
			

Diagram illustrating the assembly of the base plate. The base plate is shown with four L-shaped brackets (864) attached to its sides and four long L-shaped brackets (174) attached to its bottom edge. The orientation of the base plate is indicated by the labels RR, FR, FL, and RL, which correspond to the four corners of the base plate. The quantity of each part is indicated as x 4 for the L-shaped brackets and x 1 for the long L-shaped brackets.



1






2






754 Rapid System
480R Rapid Traverse
(North America)



x4





x4



x4




480 Traverse
(North America)





x4

3



754 Rapid System



X

NISSAN Frontier, 4-dr Crew Cab Pickup, 05–	46,5
NISSAN Frontier, 4-dr King Cab Pickup, 05–	46,5
NISSAN King Cab, 4-dr Pickup Double Cab, 05–	46,5
NISSAN Navara, 4-dr Pickup Double Cab, 05–	46,5
NISSAN Pathfinder, 5-dr SUV, 05–	46,5

Y

NISSAN Frontier, 4-dr Crew Cab Pickup, 05–	45
NISSAN Frontier, 4-dr King Cab Pickup, 05–	45
NISSAN King Cab, 4-dr Pickup Double Cab, 05–	45
NISSAN Navara, 4-dr Pickup Double Cab, 05–	45
NISSAN Pathfinder, 5-dr SUV, 05–	45

3





480R Rapid Traverse



480 Traverse



(North America)




X inch X mm

NISSAN Frontier, 4-dr Crew Cab Pickup, 05–	43 ⁷ / ₈ "	1116 mm
NISSAN Frontier, 4-dr King Cab Pickup, 05–	43 ⁷ / ₈ "	1116 mm
NISSAN King Cab, 4-dr Pickup Double Cab, 05–	43 ⁷ / ₈ "	1116 mm
NISSAN Navara, 4-dr Pickup Double Cab, 05–	43 ⁷ / ₈ "	1116 mm
NISSAN Pathfinder, 5-dr SUV, 05–	43 ⁷ / ₈ "	1116 mm

Y inch Y mm



NISSAN Frontier, 4-dr Crew Cab Pickup, 05–	43 ³ / ₈ "	1101 mm
NISSAN Frontier, 4-dr King Cab Pickup, 05–	43 ³ / ₈ "	1101 mm
NISSAN King Cab, 4-dr Pickup Double Cab, 05–	43 ³ / ₈ "	1101 mm
NISSAN Navara, 4-dr Pickup Double Cab, 05–	43 ³ / ₈ "	1101 mm
NISSAN Pathfinder, 5-dr SUV, 05–	43 ³ / ₈ "	1101 mm

4





5






NISSAN Frontier, 4-dr Crew Cab Pickup, 05–
NISSAN Frontier, 4-dr King Cab Pickup, 05–
NISSAN King Cab, 4-dr Pickup Double Cab, 05–
NISSAN Navara, 4-dr Pickup Double Cab, 05–
NISSAN Pathfinder, 5-dr SUV, 05–




6



	X mm	Y mm	X inch	Y inch
NISSAN Frontier, 4-dr Crew Cab Pickup, 05–	260 mm	750 mm	10 1/4"	29 1/2"
NISSAN Frontier, 4-dr King Cab Pickup, 05–	260 mm	610 mm	10 1/4"	24"
NISSAN King Cab, 4-dr Pickup Double Cab, 05–	260 mm	750 mm	10 1/4"	29 1/2"
NISSAN Navara, 4-dr Pickup Double Cab, 05–	260 mm	750 mm	10 1/4"	29 1/2"
NISSAN Pathfinder, 5-dr SUV, 05–	260 mm	750 mm	10 1/4"	29 1/2"







7





GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pieļieciet pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно

CZ Pokręťta багаžníka dokręcaj dokręcaj naprzemiennie.
SK Dofahujť striedavo
SLO Privijajte izmenično.
HR Naizmjenočno zategnite
HU Egymástól fűggetlenül szorítandó
GR Σφιγγετε εναλλάξ
TR Dönüşümlü sıkın
中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ชั้้นในแบบสลับ




≈ 3 Nm





8



x1
17 mm





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		



www.thule.com













info@thule.com



customer.service@thule.com



Thule Inc., 42 Silvermine Road, Seymour, Connecticut 06483, USA













NISSAN Pathfinder, 5-dr SUV, 05-	260 mm	750 mm	10 1/4"	29 1/2"
NISSAN Navara, 4-dr Pickup Double Cab, 05-	260 mm	750 mm	10 1/4"	29 1/2"
NISSAN King Cab, 4-dr Pickup Double Cab, 05-	260 mm	750 mm	10 1/4"	29 1/2"
NISSAN Frontier, 4-dr King Cab Pickup, 05-	260 mm	610 mm	10 1/4"	24"
NISSAN Frontier, 4-dr Crew Cab Pickup, 05-	260 mm	750 mm	10 1/4"	29 1/2"

X mm Y mm X inch Y inch







A



B

C









NISSAN Frontier, 4-dr Crew Cab Pickup, 05-
NISSAN Frontier, 4-dr King Cab Pickup, 05-
NISSAN King Cab, 4-dr Pickup Double Cab, 05-
NISSAN Navara, 4-dr Pickup Double Cab, 05-
NISSAN Pathfinder, 5-dr SUV, 05-





Kit

503-1430-04





instructions

Kit 1430

NISSAN Frontier, 4-dr Crew Cab Pickup, 05-
NISSAN Frontier, 4-dr King Cab Pickup, 05-
NISSAN King Cab, 4-dr Pickup Double Cab, 05-
NISSAN Navara, 4-dr Pickup Double Cab, 05-
NISSAN Pathfinder, 5-dr SUV, 05-*

* Without roof railing

480R
754



ISO 11154-E

PROFESSIONAL

THULE
SWEDEN®